



RT500/RT500RF Programmable Room Thermostat


NOTE: When an ICON is flashing, you get 10 seconds to input your data or it reverts back. SET button gets you into and out of programs. SELECT button is to confirm and move to the next step. To get into Saturday & Sunday press SELECT and the up (▲) arrow




To set the clock press and hold the SELECT and SET buttons for 3/4 seconds, you will then see the hour flashing as in picture 1. Input correct hour using your up (▲) or down (▼) buttons, making sure its on the correct AM or PM, if not, scroll through the hours until it goes to the correct setting, then press SELECT.




Now you will see the minutes flashing, same as above use the up (▲) or down (▼) buttons to set the correct minutes then press SELECT.



Now you will see the letter flashing for the correct day. If the actual day is Wednesday (W) and Monday(M) is flashing, use the arrow button to move along to Wednesday (W), then press SELECT and then SET.




To set up your programme for on time press the SET button and in the display M T W T F will flash. Press SELECT and the HOUR symbol will flash. Input the hour you want your heating to come on (ie. 9.00am) press SELECT and the minutes will flash. Input the minutes if needed and press SELECT. Now you will see TEMPERATURE flashing use up (▲) or down (▼) buttons to alter your required temperature and then press SELECT.




To set your first OFF time. Now you will see that the display has gone to PROG 2. This is the time you want your heating that you set in PROG 1 to go off. When the hour flashes input the hour you want the heating to switch off (ie. 11.30am). Press SELECT and MINUTES will flash. Input the correct minutes, press SELECT, TEMPERATURE will flash. Set this with up (▲) and down (▼) arrows and press SELECT.

Your second ON time. You will see PROG 3 displayed. This is your next on time. With the hour flashing, put in the hour and minutes you want the heating to come on (ie. 4.00pm), then press SELECT. Now TEMPERATURE will flash. Set this with up (▲) or down (▼) buttons and press SELECT.



Programme (4) is a comfort setting to raise or lower the temperature later on that you set in PROG 3. Example: In PROG 3 we set the heating to come on at 4.00pm at 22°C. If you wanted to lower the temperature at say 6.00pm to 18°C you would in PROG 4 Input 6.00pm, 18°C then press SELECT.



Now you will enter PROG 5 which is your final OFF time, so if you required your heating to switch off each weekday evening at 10.00pm to 12°C you would put this in TIME/TEMPERATURE as before press SELECT then SET.